






Wassertank Auffüllen



Schritt 1:
Klappe öffnen



Schritt 2:
Wassertank entleeren
(eignet sich gut zum Blumengießen)



Schritt 3:
Wassertank auffüllen und einsetzen

Hinweise:

- Der Wassertank muss vor dem Auffüllen des Wassers zwingend entleert werden. Wenn dieser Schritt übersprungen wird, reduziert das die Lebenszeit Ihrer Filter stark!
- Bei der Erstinbetriebnahme sollten zwei bis drei komplette Tankfüllungen sowohl in kalt als auch in warm (95°C) als Spülung gezapft werden. Dieses Wasser kann eventuell unangenehm schmecken. Sollte nach der Spülung immer noch ein unangenehmer Geschmack zurückbleiben, reinigen Sie den Tank separat und führen die Spülung erneut durch.
- Bei Fragen können Sie uns auch gerne unter der Nummer 07127/5600090 erreichen.

Rücksendung

- Bei diesem Wasserspender handelt es sich um ein Hygiene-/Lebensmittelprodukt, daher können wir keine Rückgabe akzeptieren sobald das Gerät mit Wasser befüllt wurde.
- Wenn Sie die Wasserbar aufgrund eines Defektes zurücksenden möchten, befolgen Sie die Anweisungen der Bedienungsanleitung unter Punkt „Rücksendehinweise“ und achten Sie bitte darauf, dass der innere und der äußere Wassertank so wie die Filter komplett entleert sind. Dafür besitzt unsere Wasserbar eine Entleerungsfunktion, welche Sie durch ein 5s gedrückt halten, der Wasser-Ausgabe-Taste aktivieren. Danach wird das gesamte Wasser ausgegeben. Anschließend nehmen Sie die Filter aus dem Gerät und entleeren diese, bis kein Wasser mehr heraustropft. Dazu drehen Sie die Filter nach unten und das Wasser fließt heraus. Verpacken Sie das Gerät nach der Entleerung und einer kurzen Trocknungsphase wieder in die Originalverpackung.

Bedienungsanleitung




Hier geht es zum Download der aktuellen Bedienungsanleitung


Danke, dass Sie sich für unseren Wasserspender entschieden haben. Wir wünschen Ihnen viel Freude an unserem Produkt.




Quick start information



Step 1:
Open the flap



Step 2:
Empty the water tank
(suitable for watering flowers)



Step 3:
Refill the water tank and insert

Instructions:

- The water tank must be emptied before filling up with water. Skipping this step will greatly reduce the service life of your filters!
- When starting up for the first time, two to three complete tank fillings should be tapped in both cold and warm (95°C) as a rinse. This water may taste unpleasant. If an unpleasant taste still remains after rinsing, clean the tank separately and rinse again.
- If you have any further questions, do not hesitate to contact us on 07127/5600090.

Return shipment

- This water dispenser is a hygiene/food product, therefore we cannot accept returns once the appliance has been filled with water.
- If you wish to return the water bar due to a defect, please follow the instructions in the operating instructions under "Return instruction" and make sure that the inner and outer water tanks and the filters are completely empty. Our water bar has an emptying function for this purpose, which you can activate by pressing and holding the water dispensing button for 5 seconds. All the water is then dispensed. Then remove the filters from the appliance and empty them until no more water drips out. To do this, turn the filters downwards and the water will flow out. After emptying and a short drying phase, put the appliance back in its original packaging.

Instruction manual



[Click here to download the current instruction manual](#)

Thank you for choosing our water dispenser. We hope you enjoy our product.